

4V USB Lithium™ Cordless Spray Mop (Bare Tool) RSM4-0

RYOBI



- 6,000 oscillations per minute agitates the toughest of stains to make light work of cleaning across all hard surfaces
- Twin sprayers evenly spread water and detergent at the simple press of a button to ensure a complete hygienic clean
- Hook and loop removeable microfibre pads are machine washable for on-going sustainable use, saving you money on continuous replacement pads and two are included so you'll always be ready for life's little messes
- Built into the floorhead is an LED light which helps to illuminate dirt and ensure you don't miss a spot
- Agile and swivel head means you can easily and completely clean around the contours of your home (e.g. toilet), plus it's self-standing for when you inevitably need to stop/start clean and so there's no need to worry about finding a suitable resting place



Power	4V
Cleaning Width [cm]	28
Speed settings	1
Weight with battery pack (EPTA) (kg)	1.53 (RB420)
Article Number	5133006687
Charger included	No
Charging time (min)	No charger supplied
EAN Code	4892210230829
No. of batteries supplied	0
Sound power level (Lwa) (dB(A))	66.4
Sound power level uncertainty (dB(A))	3
Sound pressure level (Lpa) (dB(A))	53.4
Sound pressure level uncertainty (dB(A))	3
Standard equipment	2x washable floor pad, 1x 250ml hard floor cleaning solution
Supplied in	Over 75% recycled cardboard carton
Vibration Level Main Handle [m/s ²]	0.68
Vibration Level Main Handle uncertainty [m/s ²]	1.5
Weight (without battery) (kg)	1.47

*Registration required for extension from 2-3 years. Please visit our site for full [T&C's](#)